

BODY PARTS LIST THE NEW AND GREATER HUDSON




APRIL 1932

Coach
Coupe Standard Sedan
Town Sedan 7-Passenger Sedan
Touring Sedan Special Sedan
Suburban

119" Cars Numbered 930770 Up
126" Cars Numbered 62884 Up
132" Cars Numbered 250001 Up

HUDSON MOTOR CAR COMPANY
DETROIT, MICHIGAN, U. S. A.



BODY PARTS LIST

THE NEW AND GREATER HUDSON

•

IMPORTANT

The use of genuine Hudson parts will insure the satisfactory operation of your car.

There are Hudson-Essex distributors and dealers in all principal cities and towns equipped to serve you.

For your own protection, insist upon obtaining genuine Hudson parts.

APRIL 1932

•

HUDSON MOTOR CAR COMPANY
DETROIT, MICHIGAN, U. S. A.

WARRANTY

"We warrant each new passenger automobile manufactured by us to be free from defects in material and workmanship under normal use and service, our obligation under this warranty being limited to making good at our factory any part or parts thereof, including all equipment or trade accessories (except tires) supplied by the car manufacturer, which shall, within ninety (90) days after making delivery of such vehicle to the original purchaser or before such vehicle has been driven 4,000 miles, whichever event shall first occur, be returned to us with transportation charges prepaid, and which our examination shall disclose to our satisfaction to have been thus defective, this warranty being expressly in lieu of all other warranties expressed or implied and of all other obligations or liabilities on our part, and we neither assume nor authorize any other person to assume for us any liability in connection with the sale of our vehicles.

"This warranty shall not apply to any vehicle which shall have been repaired or altered by other than an authorized Hudson and Essex Distributor or Dealer in any way so as, in the judgment of the manufacturer, to affect its stability or reliability nor which has been subject to misuse, negligence or accident."

HUDSON MOTOR CAR COMPANY
Detroit, Michigan, U. S. A.

INSTRUCTIONS

FOR ORDERING PARTS

- 1—Order parts through the nearest Distributor or Dealer.
- 2—Always give PART NUMBER and NAME of each part ordered.
- 3—SPECIFY SERIAL NUMBER, BODY MODEL AND COLOR ON ALL PAINTED AND TRIMMED PARTS.
- 4—Mail and Parcel Post orders should be accompanied by an amount sufficient to cover POSTAGE.
- 5—Specify how shipments are to be made.
- 6—Orders for parts should be written separately from correspondence pertaining to other matters.

TELEGRAPH CODE

To save expense, to expedite ordering and for your convenience, we list below a brief General Code covering miscellaneous instructions, questions and answers relative to the shipment of parts:

- Sultex*—Ship to me (us) by express.....
- Sulkline*—Ship by express to.....
- Sulkate*—Ship to me (us) by freight.....
- Sulmost*—Ship to me (us) by parcel post.....
- Sulwire*—When and how did you ship parts called for in my (our) telegram of.....
- Sultwich*—When and how will you ship parts called for in my (our) telegram of.....
- Sulteen*—When and how will you ship parts called for in my (our) letter of.....

INDEX

	Page
Bodies Complete	5
Cowl and Dash	5
Cowl Ventilator	5, 6
Dome Lamp	16
Doors	9, 10
Door Dovetails and Bumpers	10
Door Glass and Channels	11, 12
Door Handles	11
Door Hinges	10, 11
Door Locks	11
Door Window Regulator	12
Floor Mats, Pads and Carpets	13, 14
Foot Rest	16
Instrument Panels	5
Pillars	7
Quarter Window	11, 12
Quarter Window Regulator	12
Rear Deck Lid-2-Passenger	17, 18
Rear Deck Lid-4-Passenger	17, 18
Rear Window	11, 12
Rear Window Regulator	12
Robe Rail, Assist Cords, Etc.	16, 17
Rumble Seat	17
Rumble Seat Steps	18
Seat and Back Cushions-Front	14
Seat and Back Cushions-Rear	14
Seats-Auxiliary	16
Smoking Sets	16
Toe, Floor Boards and Scuff Plates	13, 14
Top	13
Trim Panels	7, 8, 9
Weatherstrips, Windlace and Retainers	7, 8, 9
Windshield	6

Body Abbreviations

Co.	Coach	Tw. S.	Town Sedan
Cp. (2)	2-Pass. Coupe	7 S.	7-Pass. Sedan
Cp. (4)	4-Pass. Coupe	To. S.	Touring Sedan
Cp. S.	Special Coupe	Sp. S.	Special Sedan
S. S.	Standard Sedan	Sub.	Suburban

BODY—L. H. D

Part No.	Description	Specifications	Co.	Cp.(2)	Cp.(4)	SS	Tw. S	7S.	To.S	Sp. S	Sub	Cp.S
CO 94611	Body complete		1									
CO 94617	Body complete			1								
CO 94619	Body complete				1							
CO 94615	Body complete					1						
CO 94613	Body complete						1					
CO 94625	Body complete							1				
CO 94627	Body complete								1			
CO 94621	Body complete									1		
CO 94623	Body complete										1	
CO 95286	Body complete											1
BO 12320	Body bolt		10	10	10	10	10	10	10	10	8	10
BO 70011	Body bolt		2	2	2	2	2	2	2	2		2
BO 70947	Body bolt										2	
BO 70573	Body bolt nut		12	12	12	12	12	12	12	12	10	12

BODY—R. H. D.

Part No.	Description	Specifications	Co.	Cp.(2)	Cp.(4)	SS	Tw. S	7S.	To.S	Sp. S	Sub	Cp.S
CO 94612	Body complete		1									
CO 94618	Body complete			1								
CO 94620	Body complete				1							
CO 94616	Body complete					1						
CO 94614	Body complete						1					
CO 94626	Body complete							1				
CO 94628	Body complete								1			
CO 94622	Body complete									1		
CO 94624	Body complete										1	
CO 95287	Body complete											1

(Standard parts are same as in preceding group)

FRONT END

Part No.	Description	Specifications	Co.	Cp.(2)	Cp.(4)	SS	Tw. S	7S.	To.S	Sp. S	Sub	Cp.S
CO 94161	Front end assy.		1	1	1	1	1	1	1	1	1	1
CO 94162	Front end frame assy.		1	1	1	1	1	1	1	1	1	1
BO 94906	Anchor bolt No. 1 bracket assy.—R. H		1	1	1	1	1	1	1	1	1	1
BO 94907	Anchor bolt No. 1 bracket assy.—L. H.		1	1	1	1	1	1	1	1	1	1
BO 94560	Body front end to roof bracket—R. H		1	1	1	1	1	1	1	1	1	1
BO 94561	Body front end to roof bracket—L. H.		1	1	1	1	1	1	1	1	1	1
BO 94963	Body front end to dash brace assy		2	2	2	2	2	2	2	2	2	2
BO 94535	Radiator stay rod dash bracket		2	2	2	2	2	2	2	2	2	2
BO 70397	Wire and loom clip clinch nut		6	6	6	6	6	6	6	6	6	6
BO 70399	Toe plate and vacuum tank clinch nut		10	10	10	10	10	10	10	10	10	10
BO 99087	Steering gear jacket tube bracket assy		1	1	1	1	1	1	1	1	1	1
BO 1061	Steering gear jacket tube bracket bolt		2	2	2	2	2	2	2	2	2	2
BO 95406	Steering gear jacket tube clamp		1	1	1	1	1	1	1	1	1	1
BO 394	Steering gear jacket tube clamp bolt		1	1	1	1	1	1	1	1	1	1
BO 5402	Steering gear jacket tube clamp bolt lock nut		1	1	1	1	1	1	1	1	1	1
BO 95407	Steering gear jacket tube bracket bushing		2	2	2	2	2	2	2	2	2	2
CO 95451	(half)		1	1	1	1	1	1	1	1	1	1
BO 70740	Instrument panel assy.		6	6	6	6	6	6	6	6	6	6
BO 70397	Instrument panel to belt reinforcement screw		6	6	6	6	6	6	6	6	6	6
	Instrument panel to glove box clinch nut											

COWL VENTILATOR

A 85788	Cover assy.—R. H		1	1	1	1	1	1	1	1	1	1
A 86006	Cover assy.—L. H		1	1	1	1	1	1	1	1	1	1
BO 96028	Drain tube		2	2	2	2	2	2	2	2	2	2
BO 87600	Cover hinge—R. H.		2	2	2	2	2	2	2	2	2	2
BO 87601	Cover hinge—L. H.		2	2	2	2	2	2	2	2	2	2
BO 85421	Roller guide—R. H		2	2	2	2	2	2	2	2	2	2
BO 85422	Roller guide—L. H		2	2	2	2	2	2	2	2	2	2
BO 85423	Ratchet roller		2	2	2	2	2	2	2	2	2	2
BO 85424	Trough hinge spacer		4	4	4	4	4	4	4	4	4	4
BO 85425	Spring		2	2	2	2	2	2	2	2	2	2
BO 94410	Handle		2	2	2	2	2	2	2	2	2	2
BO 94409	Drain hose clip		2	2	2	2	2	2	2	2	2	2
BO 85426	Weatherstrip		2	2	2	2	2	2	2	2	2	2

COWL VENTILATOR—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	SS	Tw. S	7S.	To. S	Sp. S	Sub
BO 70028	Ratchet rivet	3/16"x3/8"	4	4	4	4	4	4	4	4	4
BO 18447	Handle screw	No. 10-32x5/8"	2	2	2	2	2	2	2	2	2
BO 12799	Handle screw nut	No. 10-32x5/8"	2	2	2	2	2	2	2	2	2
BO 94408	Reinforcement—drain trough		1	1	1	1	1	1	1	1	1
BO 18318	Reinforcement—drain trough screw	1/4"-20x3/4"	2	2	2	2	2	2	2	2	2
BO 70676	Reinforcement—drain trough nut	1/4"-20x1/4"	2	2	2	2	2	2	2	2	2

WINDSHIELD

CO 94836	Windshield assy. (less glass)		1	1	1	1	1	1	1	1	1
95264	Windshield glass (not supplied)		1	1	1	1	1	1	1	1	1
CO 94827	Windshield hinge assy. (body half)		1	1	1	1	1	1	1	1	1
BO 18447	Windshield hinge attaching screw		9	9	9	9	9	9	9	9	9
BO 94828	Windshield hinge weatherstrip		1	1	1	1	1	1	1	1	1
BO 95477	Windshield bumper		1	1	1	1	1	1	1	1	1
BO 96242	Windshield regulator assy.		1	1	1	1	1	1	1	1	1
BO 99017	Windshield regulator body bracket		1	1	1	1	1	1	1	1	1
BO 99020	Windshield regulator body bracket rivet		1	1	1	1	1	1	1	1	1
BO 96685	Windshield regulator finish plate		1	1	1	1	1	1	1	1	1
BO 99018	Windshield regulator spring and sleeve		1	1	1	1	1	1	1	1	1
BO 86277	assy		1	1	1	1	1	1	1	1	1
BO 90041	Windshield regulator spring escutcheon		2	2	2	2	2	2	2	2	2
BO 99019	Windshield regulator finish plate screw		2	2	2	2	2	2	2	2	2
BO 99026	Windshield regulator rivet		1	1	1	1	1	1	1	1	1
BO 94829	Windshield weatherstrip (sides and bot-		2	2	2	2	2	2	2	2	2
BO 94830	tom)		2	2	2	2	2	2	2	2	2
	Windshield corner rubber										
	Windshield corner rubber clip										

PANELS—METAL

CO 94002	Cowl side panel—R. H.		1	1	1	1	1	1	1	1	1
CO 94003	Cowl side panel—L. H.		1	1	1	1	1	1	1	1	1
CO 94005	Front end panel		1	1	1	1	1	1	1	1	1
CO 94027	Visor panel		1	1	1	1	1	1	1	1	1
CO 94006	Dash panel		1	1	1	1	1	1	1	1	1
CO 94058	Rear panel		1	1	1	1	1	1	1
CO 94293	Rear panel—upper		..	1	1
CO 94294	Rear panel—lower		..	1	1
CO 94048	Quarter panel—R. H.		1
CO 94049	Quarter panel—L. H.		1
CO 94046	Quarter panel—R. H.		1
CO 94047	Quarter panel—L. H.		1
CO 94104	Quarter panel—R. H.		1
CO 94105	Quarter panel—L. H.		1
CO 94056	Quarter panel—R. H..		1	..
CO 94057	Quarter panel—L. H..		1	..
CO 94050	Quarter panel—R. H..		1
CO 94051	Quarter panel—L. H.		1
CO 94234	Quarter panel—R. H.		1	1
CO 94235	Quarter panel—L. H.		1	1
CO 94297	Quarter panel—R. H.		..	1	1
CO 94298	Quarter panel—L. H.		..	1	1
CO 95144	Deck panel—lower—inside		..	1	1
CO 94299	Deck door panel—outside		1
CO 94926	Deck door panel—outside		..	1
CO 94854	Deck door panel—inside		..	1	1
CO 94028	Roof side panel—R. H.		1	1	1	..
CO 94029	Roof side panel—L. H.		1	1
CO 94151	Roof side panel—R. H.		1	1
CO 94152	Roof side panel—L. H.		1	1
CO 94282	Roof side panel—R. H.		1	1
CO 94283	Roof side panel—L. H.		1	1
CO 94432	Roof side panel—R. H.		..	1	1
CO 94433	Roof side panel—L. H..		..	1	1
CO 94111	Front door panel—outside—R. H.		1	1	1	..	1

Specify serial number, body model and color on all painted or trimmed parts

PANELS—METAL—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	SS	Tw. S	7S.	To.S	Sp. S	Sub
CO 94112	Front door panel—outside—L. H.		1	1	1	..
CO 94113	Front door panel—outside—R. H.		1	1	1	1
CO 94114	Front door panel—outside—L. H.		1	1	1	1
CO 94380	Front door panel—outside—R. H.		1	1
CO 94381	Front door panel—outside—L. H.		1	1
CO 94266	Rear door panel—outside--R. H.		1
CO 94267	Rear door panel—outside—L. H.		1
CO 94268	Rear door panel—outside—R. H.		1
CO 94269	Rear door panel—outside—L. H.		1
CO 94286	Rear door panel—outside—R. H.		1	1
CO 94287	Rear door panel—outside—L. H.		1	1
CO 94288	Rear door panel—outside—R. H.		1	1	..
CO 94289	Rear door panel—outside—L. H.		1	1	..

PILLARS

CO 94192	Body hinge pillar assy.—R. H.		1	1
CO 94193	Body hinge pillar assy.—L. H.		1	1
CO 95584	Body hinge pillar assy.—R. H.	
CO 95585	Body hinge pillar assy.—L. H.	
CO 94190	Center pillar assy.—R. H.		1	1	1	1	1	..
CO 94191	Center pillar assy.—L. H.		1	1	1	1	1	..
CO 94194	Rear body pillar assy.—R. H.		1
CO 94195	Rear body pillar assy.—L. H.		1
CO 94196	Rear body pillar assy.—R. H.	
CO 94197	Rear body pillar assy.—L. H.	
CO 94198	Rear body pillar assy.—R. H.		1	..
CO 94199	Rear body pillar assy.—L. H.		1	..
CO 94200	Rear body pillar assy.—R. H.		1	1
CO 94201	Rear body pillar assy.—L. H.		1	1

*TRIM PANELS—WEATHERSTRIPS AND WINDLACE

CO 93493	Windshield header finish panel assy		1	1	1	1	1	1	1	1	1
CO 93521	Front door trim panel and pocket assy.—R. H.		1	1†
CO 93531	Front door trim panel and pocket assy.—L. H.		1	1†
CO 93525	Front door trim panel and pocket assy.—R. H.		..	1	1	1	1
CO 93533	Front door trim panel and pocket assy.—L. H.		..	1	1	1	1
CO 93547	Front door trim panel and pocket and arm rest assy.—R. H.		1 Spec.	1	..
CO 93529	Front door trim panel and pocket and arm rest assy.—L. H.		1 Spec.	1	..
CO 97443†	Front door trim panel pocket and arm rest assy.—R. H.		1	1	..	1
CO 97444†	Front door trim panel pocket and arm rest assy.—L. H.		1	1	..	1
CO 97627	Front door trim panel and pocket assy.—R. H.		1
CO 97628	Front door trim panel and pocket assy.—L. H.		1
CO 97649	Front door trim panel and pocket assy.—R. H.		..	1	1	1	1
CO 97650	Front door trim panel and pocket assy.—L. H.		..	1	1	1	1
CO 97675	Front door trim panel and pocket and arm rest assy.—R. H.		1 Spec.	1	..
CO 97676	Front door trim panel and pocket and arm rest assy.—L. H.		1 Spec.	1	..
CO 97679	Front door trim panel and pocket and arm rest assy.—R. H.		1	1	..	1
CO 97680	Front door trim panel and pocket and arm rest assy.—L. H.		1	1	..	1

Used with 1 1/4" pull-to cord

Used with 2 1/4" pull-to cord

*TRIM PANELS—WEATHERSTRIPS AND WINDLACE—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S	Sub.
CO 92070	Rear door trim panel and pocket assy.—R. H.		1	1
CO 92071	Rear door trim panel and pocket assy.—L. H.		1	1
CO 93541	Rear door trim panel assy.—R. H.		1
CO 93545	Rear door trim panel assy.—L. H.		1
CO 93382	Rear body pillar windlace assy.—R. H. upper		1
CO 93383	Rear body pillar windlace assy.—L. H. upper		1
CO 93384	Rear body pillar windlace assy.—R. H. lower		1
CO 93385	Rear body pillar windlace assy.—L. H. lower		1
CO 93331	Rear body pillar windlace assy.—R. H.		1
CO 93332	Rear body pillar windlace assy.—L. H.		1
CO 93343	Body header windlace assy		2	2
CO 93340	Body header windlace assy		2	2
CO 93342	Body header windlace assy		2	2	..
CO 93339	Body header windlace assy		..	2	2	..	2
CO 93341	Body header windlace assy	
CO 93326	Front end body pillar windlace assy.—R. H.		1	1	1	1	1	1	1	1	1
CO 93327	Front end body pillar windlace assy.—L. H.		1	1	1	1	1	1	1	1	1
CO 93324	Body hinge pillar windlace assy.—R. H.		1	1	1	1
CO 93325	Body hinge pillar windlace assy.—L. H.		1	1	1
CO 93400	Center pillar windlace and trimstick assy.		1	1	1	1	1	1
BO 93141	Door pocket slide fastener complete—R. H.		1	1	1	1	1	1	1	1	1
BO 93142	Door pocket slide fastener complete—L. H.		1	1	1	1	1	1	1	1	1
BO 97061	Door pocket slide fastener tip and chain assy		2	2	2	2	2	2	2	2	2
CO 93128	Cowl side trim panel—R. H.		1	1	1	1	1	1	1	1	1
CO 93129	Cowl side trim panel—L. H.		1	1	1	1	1	1	1	1	1
CO 93539	Rear door trim panel assy.—R. H.		1
CO 93543	Rear door trim panel assy.—L. H.		1
CO 92061	Rear door trim panel and pocket assy.—R. H.		1	..
CO 92062	Rear door trim panel and pocket assy.—L. H.		1	1
CO 97045	Lower quarter trim panel and windlace assy.- R. H.		1	1
CO 97046	Lower quarter trim panel and windlace assy.- L. H.		1	1
CO 93635	Lower quarter trim panel and windlace assy.- R. H.	
CO 93636	Lower quarter trim panel and windlace assy.- L. H.		1	..
CO 97041	Lower quarter trim panel and windlace assy.- R. H.		1	..
CO 97042	Lower quarter trim panel and windlace assy.- L. H.	
CO 93513	Lower quarter trim panel and windlace assy.- R. H.		1
CO 93514	Lower quarter trim panel and windlace assy.- L. H.		1
CO 93482	Quarter trim panel and windlace assy. com- plete—		..	1	1
CO 93483	R. H.		..	1	1
CO 97037	Quarter trim panel and windlace assy. com- plete—		..	1	1
CO 97038	L. H.		1
CO 97038	Lower quarter trim panel and windlace assy.- R. H.		1
CO 93470	Lower quarter trim panel and windlace assy.- L. H.	
CO 93471	Upper quarter trim panel and windlace assy.- R. H.	
CO 93517	Upper quarter trim panel and windlace assy.- L. H.	
CO 93518	Lower quarter trim panel and windlace assy.- R. H.	
CO 97049	Lower quarter trim panel and windlace assy.- L. H.		1 Spec.	1	1	1	1
CO 97050	L. H.		1 Spec.	1	1	1	1
CO 93018	Front door arm rest assy.—R. H.		1	1
	Front door arm rest assy.—L. H.		1	1
	Quarter arm rest assy.—R. H.		1	1

Specify serial number, body model and color on all painted or trimmed parts

*TRIM PANELS—WEATHERSTRIPS AND WINDLACE—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S	Sub.
CO 93019	Quarter arm rest assy.—L. H	
CO 93671	Quarter arm rest assy.—R. H		1
CO 93672	Quarter arm rest assy.—L. H		1
CO 93010	Quarter arm rest assy.—R. H	
CO 93011	Quarter arm rest assy.—L. H	
CO 93687	Quarter arm rest assy.—R. H		1
CO 93688	Quarter arm rest assy.—L. H		1
CO 93335	Front frame pillar trim panel and windlace assy.—R. H		1	1	1	1	1	1	1	1	1
CO 93336	Front frame pillar trim panel and windlace assy.—L. H		1	1	1	1	1	1	1	1	1
CO 93491	Rear window curtain retainer and trim assy		1	1	1	1	1	1	1
CO 93493	Windshield header trim panel assy		1	1	1	1	1	1	1	1	1
CO 93596	Inside visor assy.		2 Spec.	2	2	2	2
CO 93337	Rear body pillar windlace assy.—R. H.		1	1
CO 93338	Rear body pillar windlace assy.—L. H		1	1
CO 93333	Rear body pillar windlace assy.—R. H.		1	..
CO 93334	Rear body pillar windlace assy.—L. H		1	..

*IMPORTANT—Specify car serial number and color on all trimmed parts

† Panel Nos. 97443 and 97444 used on Suburban from car No. 63337 until short cord was discontinued.

Doors

CO 97137	Door complete—R. H.		1	1	
CO 97138	Door complete—L. H.		1	1	
CO 97369	Door complete—R. H		..	1	1	
CO 97370	Door complete—L. H		..	1	1	
CO 97145	Door complete—R. H.—front		1	1	1	1	
CO 97146	Door complete—L. H.—front		1	1	1	1	
CO 97373	Door complete—R. H.		1 Spec.	
CO 97374	Door complete—L. H.		1 Spec.	
CO 97153	Door complete—R. H.—front	Used with 1 3/8" pull-to cord	1	..	
CO 97154	Door complete—L. H.—front		1	..
CO 97157	Door complete—R. H.—front		1	1
CO 97158	Door complete—L. H.—front		1	1
CO 97623	Door complete—R. H		..	1
CO 97624	Door complete—L. H		..	1
CO 97645	Door complete—R. H		1	1	..
CO 97646	Door complete—L. H		1	1	..
CO 97637	Door complete—R. H.—front		1	1	1	1
CO 97638	Door complete—L. H.—front		1	1	1	1
CO 97659	Door complete—R. H.	1 Spec.	
CO 97660	Door complete—L. H	1 Spec.	
CO 97667	Door complete—R. H.—front	1	..	
CO 97668	Door complete—L. H.—front	1	..	
CO 97671	Door complete—R. H.—front	1	1	..	1	..	
CO 97672	Door complete—L. H.—front	1	1	..	1	..	
CO 97173	Door complete—R. H.—rear	1	
CO 97174	Door complete—L. H.—rear	1	
CO 97177	Door complete—R. H.—rear	1	
CO 97178	Door complete—L. H.—rear	1	
CO 97181	Door complete—R. H.—rear	1	..	
CO 97182	Door complete—L. H.—rear	1	..	
CO 97185	Door complete—R. H.—rear	1	1	
CO 97186	Door complete—L. H.—rear	1	1	
CO 96714	Door assy.—R. H.—front—skeleton	..	1	1	1	..	1	
CO 96715	Door assy.—L. H.—front—skeleton	..	1	1	1	..	1	
CO 96718	Door assy.—R. H.—skeleton	..	1	1	
CO 96719	Door assy.—L. H.—skeleton	..	1	1	
CO 96722	Door assy.—R. H.—front—skeleton	1	1	1	..	
CO 96723	Door assy.—L. H.—front—skeleton	1	1	1	..	
CO 96728	Door assy.—R. H.—rear—skeleton	1	

Used with 2 2/4" pull-to cord

DOORS—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw. S.	7 S.	To. S.	Sp. S.	Sub.
CO 96729	Door assy.—L. H.—rear—skeleton	1
CO 96730	Door assy.—R. H.—rear—skeleton	1
CO 96731	Door assy.—L. H.—rear—skeleton	1
CO 96732	Door assy.—R. H.—rear—skeleton	1	..
CO 96733	Door assy.—L. H.—rear—skeleton	1	..
CO 96734	Door assy.—R. H.—rear—skeleton	1	1
CO 96735	Door assy.—L. H.—rear—skeleton	1	1
BO 94915	Door check strap	2	2	2	4	4	4	4	4	4	2
BO 94697	Door check strap bumper	2	2	2	4	4	4	4	4	4	2
BO 96089	Door check strap anti-rattle spring	2	2	2	4	4	4	4	4	4	2
BO 70854	Door check strap to bracket clevis pin	2	2	2	4	4	4	4	4	4	2
BO 94831	Door dovetail complete—female	2	2	2	4	4	4	4	4	4	2
BO 94870	Door dovetail—male	2	2	2	4	4	4	4	4	4	2
BO 70853	Door dovetail screw	8	8	8	16	16	16	16	16	16	8
BO 94541	Door dovetail plate	2	2	2	4	4	4	4	4	4	2
BO 94542	Door dovetail plate retainer	2	2	2	4	4	4	4	4	4	2
BO 96853	Door lock striker plate—front	2	2	2	2	2	2	2	2	2	2
BO 96854	Door lock striker plate—rear	2	2	2	2	2	2	..
BO 96855	Door lock striker plate—felt—front	2	2	2	2	2	2	2	2	2	2
BO 96856	Door lock striker plate—felt—rear	2	2	2	2	2	2	..
BO 70853	Door lock striker plate screw	4	4	4	8	8	8	8	8	8	4
BO 94427	Door lock striker plate tapping plate	2	2	2	4	4	4	4	4	4	2
BO 94426	Door lock striker plate tapping plate retainer	2	2	2	4	4	4	4	4	4	2
BO 96663	Door bumper—upper—front	2	2	2	2	2	2	2	2	2	2
BO 75151	Door bumper	2	2	2	6	6	6	6	6	6	2
BO 75152	Door bumper retainer	4	4	4	8	8	8	8	8	8	4
BO 70865	Door bumper retainer screw	4	4	4	8	8	8	8	8	8	4
BO 94834	Door dovetail bumper	4	4	4	8	8	8	8	8	8	4
BO 94833	Door dovetail bumper retaining spring	2	2	2	4	4	4	4	4	4	2

DOOR HINGES

BO 94501	Lower hinge bracket and hinge assy. (rear pillar) —R. H.	1	1
BO 94502	Lower hinge bracket and hinge assy. (rear pillar) —L. H.	1	1
BO 94503	Lower hinge bracket and hinge assy. (rear pillar) —R. H.	1
BO 94504	Lower hinge bracket and hinge assy. (rear pillar) —L. H.	1
BO 94505	Lower hinge bracket and hinge assy. (rear pillar) —R. H.	1	1
BO 94506	Lower hinge bracket and hinge assy. (rear pillar) —L. H.	1	1
BO 94497	Upper bracket and hinge assy. (center and hinge pillar)—R. H.	1	1	1	1	1	1	1	1	1	1
BO 94498	Upper bracket and hinge assy. (center and hinge pillar)—L. H.	1	1	1	1	1	1	1	1	1	1
BO 94499	Lower bracket and hinge assy. (center pillar) —R. H.	1	1	1	1	1	1	1	1	1	1
BO 94500	Lower bracket and hinge assy. (center pillar) —L. H.	1	1	1	1	1	1	1	1	1	1
BO 95196	Upper bracket and hinge assy. (rear pillar)—R. H.	1	1	1	1	1	1	..
BO 95197	Upper bracket and hinge assy. (rear pillar)—L. H.	1	1	1	1	1	1	..
BO 94784	Hinge—upper—front door half—R. H.	1	1	1	1	1	1	1	1	1	1
BO 94785	Hinge—upper—front door half—L. H.	1	1	1	1	1	1	1	1	1	1
BO 94786	Hinge—lower—front door half—R. H.	1	1	1	1	1	1	1	1	1	1
BO 94787	Hinge—lower—front door half—L. H.	1	1	1	1	1	1	1	1	1	1
BO 94790	Hinge—upper—rear door half—R. H.	1	1	1	1	1	1	..
BO 94791	Hinge—upper—rear door half—L. H.	1	1	1	1	1	1	..
BO 94792	Hinge—lower—rear door half—R. H.	1	1	1	1	1	1	..
BO 94793	Hinge—lower—rear door half—L. H.	1	1	1	1	1	1	..
BO 94780	Hinge pin—upper	2	2	2	4	4	4	4	4	4	2
BO 94781	Hinge pin—lower	2	2	2	4	4	4	4	4	4	2
BO 94457	Upper hinge bracket—R. H.	1	1	1	2	2	2	2	2	2	1

DOOR HINGES—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S.	Sub.
BO 94458	Upper hinge bracket—L. H.		1	1	1	2	2	2	2	2	1
BO 94456	Hinge reinforcement—lower—front		2	2	2	2	2	2	2	2	2
BO 94459	Lower hinge bracket—R. H.—rear door		1
BO 94460	Lower hinge bracket—L. H.—rear door		1
BO 94461	Lower hinge bracket—R. H.—rear door		1
BO 94462	Lower hinge bracket—L. H.—rear door		1
BO 94463	Lower hinge bracket—R. H.—rear door		1	..
BO 94464	Lower hinge bracket—L. H.—rear door		1	..
BO 94465	Lower hinge bracket—R. H.—rear door		1	1
BO 94466	Lower hinge bracket—L. H.—rear door		1	1
BO 18474	Hinge rivet		*	*	*	*	*	*	*	*	*

DOOR HANDLES AND LOCKS

BO 94587	Lock assy.—L. H.—front		1	1	1	1	1	1	1	1	1
BO 94588	Lock assy.—R. H.—front		1	1	1	1	1	1	1	1	1
BO 94589	Lock assy.—R. H.—rear		1	1	1	1	1	..
BO 94590	Lock assy.—L. H.—rear		1	1	1	1	1	..
BO 18464	Lock screw		6	6	6	12	12	12	12	12	6
BO 94581	Lock remote control assy.—rear—R. H.		1	1	1	1	1	..
BO 94582	Lock remote control assy.—rear—L. H.		1	1	1	1	1	..
BO 18447	Lock remote control assy. screw		6	6	6	6	6	..
BO 95121	Inside handle		2	2	2	4	4	4	4	4	2
BO 95136	Inside handle escutcheon plate		2	2	2	4	4	4	4	4	2
BO 95901	Outside handle and cylinder assy		1	1	1	1	1	1	1	1	1
BO 95911	Outside handle (less cylinder)		1	1	1	1	1	1	1	1	1
BO 95817	Outside handle locking cylinder		1	1	1	1	1	1	1	1	1
BO 95902	Outside handle—L. H.—front		1	1	1	1	1	1	1	1	1
BO 95905	Outside handle—R. H.—rear		1	1	1	1	1	..
BO 95906	Outside handle—L. H.—rear		1	1	1	1	1	..
BO 70526	Outside handle screw		4	4	4	8	8	8	8	8	4
BO 92327	Pull-to cord assy.—front (knitted end type) Pull-	14-3/4"	2	2	2	4
BO 92332	to cord assy.—front	14-3/4"	2 Spec.	2	2
BO 92337	Pull-to cord assy.—front and rear	14-3/4"	4	4	4
BO 92333	Pull-to cord assy.—rear	17-3/4"	2	..
BO 92328	Pull-to cord assy.—rear	17-3/4"
BO 97574	Pull-to cord assy.—front (bound end type)	22-1/4"	2	2	2	2
BO 97595	Pull-to cord assy.—front	22-1/4"	2 Spec.	2	2
BO 97598	Pull-to cord assy.—front	22-1/4"	2	2
BO 97597	Pull-to cord assy.—rear	14-3/4"	2	2

WINDOWS AND REGULATORS

95164	Door glass—front (not supplied) (plate)		2	2
95165	Door glass—front (not supplied) (shatterproof)		2	..
95166	Door glass—front (not supplied) (plate)		..	2	2
95168	Door glass—front (not supplied) (plate)		2
95169	Door glass—front (not supplied) (shatterproof)		2	2	..	2
95178	Door glass—rear (not supplied) (plate)		2
95179	Door glass—rear (not supplied) (shatterproof)		2	..
95180	Door glass—rear (not supplied) (plate)	
95181	Door glass—rear (not supplied) (shatterproof)		2	2
95170	Quarter glass (not supplied)		..	2	2
95172	Quarter glass (not supplied) (plate)		2
95173	Quarter glass (not supplied) (shatterproof)		2	..
95175	Quarter glass (not supplied) (shatterproof)		2	2
95176	Quarter glass (not supplied) (plate)		2
95177	Quarter glass (not supplied) (shatterproof)		2
95182	Rear window glass (not supplied)		1	1	1	1	1	1	1
95183	Rear window glass (not supplied)		..	1	1
BO 95511	Door glass run and clip assy.—front door front		2	2	2	2	2	2	2	2	2
BO 95509	Door glass run and clip assy.—front door rear and rear door front		2	2	2	4	4	4	4	4	2
BO 95506	Door glass run and clip assy.—rear		2	2
BO 95507	Door glass run and clip assy.—rear		2	..
BO 95508	Door glass run and clip assy.—rear		2	2

WINDOWS AND REGULATORS—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw. S.	7 S.	To. S.	Sp. S	Sub.
BO 94575	Door glass rest channel assy.—R. H.—front		..	1	1	1	1	1	..
BO 94576	Door glass rest channel assy.—L. H.—front		..	1	1	1	1	1	..
BO 94577	Door glass rest channel assy.—R. H.—front		1	1	1	..	1
BO 94578	Door glass rest channel assy.—L. H.—front		1	1	1	..	1
BO 94573	Door glass rest channel assy.—R. H.—rear		1	1	..
BO 94574	Door glass rest channel assy.—L. H.—rear		1	1	..
BO 94579	Door glass rest channel assy.—R. H.—rear		1	1	1
BO 94580	Door glass rest channel assy.—L. H.—rear		1	1	1
BO 96485	Door glass rubber bumper		2	2	2	4	4	4	4	4	2
BO 96493	Door glass header weatherstrip assy.—front		..	2	2	2	2	2
BO 96494	Door glass header weatherstrip assy.—front		2	2	2	2
BO 96491	Door glass header weatherstrip assy.—rear		2	2	..
BO 96492	Door glass header weatherstrip assy.—rear		2	2	2
CO 95386	Door window finish moulding assy.—R. H.—front		1	1	1	..	1
CO 95387	Door window finish moulding assy.—L. H.—front		1	1	1	..	1
CO 95388	Door window finish moulding assy.—R. H.—front		1	1	1	..
CO 95389	Door window finish moulding assy.—L. H.—front		1	1	1	..
CO 95390	Door window finish moulding assy.—R. H.—front		..	1	1
CO 95391	Door window finish moulding assy.—L. H.—front		..	1	1
BO 95392	Door window finish moulding assy.—R. H.—rear		1	1	..
BO 95393	Door window finish moulding assy.—L. H.—rear		1	1	..
CO 95394	Door window finish moulding assy.—R. H.—rear		1	1	1
CO 95395	Door window finish moulding assy.—L. H.—rear		1	1	1
CO 95396	Quarter window finish moulding assy.—R. H..		1	1
CO 95397	Quarter window finish moulding assy.—L. H.		1	1
CO 95398	Quarter window finish moulding assy.—R. H		1	1	..
CO 95399	Quarter window finish moulding assy.—L. H		1	1	..
CO 95400	Quarter window finish moulding assy.—R. H..		1	1
CO 95401	Quarter window finish moulding assy.—L. H		1	1
CO 95350	Quarter window finish moulding assy.—R. H		..	1	1
CO 95351	Quarter window finish moulding assy.—L. H		..	1	1
BO 95510	Quarter window glass run and clip assy.		4	4	..	4	4	4	4
CO 94667	Quarter window rest channel assy.—R. H		1	1
CO 94668	Quarter window rest channel assy.—L. H.		1	1
CO 94669	Quarter window rest channel assy.—R. H		1	1	..
CO 94670	Quarter window rest channel assy.—L. H.		1	1	..
CO 94671	Quarter window rest channel assy.—R. H		1	1
CO 94672	Quarter window rest channel assy.—L. H		1	1
BO 95218	Rear window rest channel assy		..	1	1
BO 96485	Quarter window glass bumper		2	2
BO 95521	Quarter window glass header weatherstrip		2	2
BO 95522	Quarter window glass header weatherstrip		2	2	..
BO 95523	Quarter window glass header weatherstrip		2	2
BO 95493	Rear window glass header weatherstrip		..	1	1
BO 95355	Rear window finish moulding assy		..	1	1
BO 94583	Door window regulator assy.—R. H.—front		1	1	1	1	1	1	1	1	1
BO 94584	Door window regulator assy.—L. H.—front		1	1	1	1	1	1	1	1	1
BO 94585	Door window regulator assy.—R. H.—rear		1	1	1	1	1	..
BO 94586	Door window regulator assy.—L. H.—rear		1	1	1	1	1	..
BO 86273	Quarter window regulator assy.—R. H		1	..	1	1	1	..
BO 86274	Quarter window regulator assy.—L. H.		1	..	1	1	1	..
BO 86103	Quarter and rear window regulator assy.—R. H		1	1	1	1
BO 86104	Quarter window regulator assy.—L. H		1	1
BO 70865	Door window regulator to frame screw		8	8	8	16	16	16	16	16	8
BO 18475	Door window regulator to frame screw shakeproof washer		8	8	8	16	16	16	16	16	8
BO 18218	Quarter window regulator to frame screw		8	4	4	8	..	8	8	8	8
BO 18475	Quarter window regulator to frame screw shakeproof washer		8	4	4	8	..	8	8	8	8
BO 96244	Door and quarter window regulator handle assy.		4	2	2	4	4	4	4	4	4
BO 96243	Quarter and rear window regulator handle assy.		..	1	1	2	..	2	2	2	..
BO 79308	Window regulator handle pin		6	5	5	10	8	10	10	10	6
BO 96125	Window regulator handle spring		6	5	5	10	8	10	10	10	6
BO 95136	Window regulator escutcheon plate		6	5	5	10	8	10	10	10	6

Specify serial number, body model and color on all painted or trimmed parts

TOP

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S	Sub.
CO 94523	Roof diagonal strap		2	2	2
CO 94524	Roof diagonal strap		..	2	2
CO 94521	Roof diagonal strap		2	2
CO 94522	Roof diagonal strap		2	2	..
BO 70096	Roof diagonal strap bolt		2	2	2	2	2	2	2	2	2
BO 12481	Roof diagonal strap bolt nut		2	2	2	2	2	2	2	2	2
CO 95226	Roof rail—front—R. H.		1	1	1	1	1	1	1
CO 95227	Roof rail—front—L. H.		1	1	1	1	1	1	1
CO 95236	Roof rail—front—R. H.		..	1	1
CO 95237	Roof rail—front—L. H.		..	1	1
CO 95230	Roof rail—rear—R. H.		1	1	..
CO 95231	Roof rail—rear—L. H.		1	1	..
CO 95232	Roof rail—rear—R. H.		..	1	1
CO 95233	Roof rail—rear—L. H.		..	1	1
CO 95234	Roof rail—rear—R. H.		1	1
CO 95235	Roof rail—rear—L. H.		1	1
CO 95228	Roof rail—rear—R. H.		1	1	1
CO 95229	Roof rail—rear—L. H.		1	1	1
CO 94820	Roof bow No. 1		1	1	1	1	1	1	1	1	1
CO 94821	Roof bow No. 2		1	1	1	1	1	1	1
CO 94822	Roof bow Nos. 3, 4, 5, 6 and 7		4	4	4	5	5	4	4
CO 94823	Roof bow Nos. 2 and 3		..	2	2
CO 94824	Roof bow No. 4		..	1	1
CO 95945	Roof bow—rear		1	1	1	1	1	1	1
CO 95565	Roof moulding—front		1	1	1	1	1	1	1	1	1
CO 95566	Roof moulding—rear—R. H.		1	1
CO 95567	Roof moulding—rear—L. H.		1	1	1
CO 95568	Roof moulding—rear—R. H.		1	1	..
CO 95569	Roof moulding—rear—L. H.		1	1	..
CO 95570	Roof moulding—rear—R. H.		1	1
CO 95571	Roof moulding—rear—L. H.		1	1
CO 95572	Roof moulding—rear—R. H.		..	1	1
CO 95573	Roof moulding—rear—L. H.		..	1	1
CO 95575	Roof moulding filler		1	1
CO 95576	Roof moulding filler		1
CO 95577	Roof moulding filler		1	1
CO 95578	Roof moulding filler		..	1	1
BO 70913	Roof moulding tack		*	*	*	*	*	*	*	*	*
BO 99090	Radio antenna	
BO 99091	Radio antenna		1	1	1	..
CO 94904	Toe board riser assy.—R. H		1	1	1	1	1	1	1	1	1
CO 94905	Toe board riser assy.—L. H		1	1	1	1	1	1	1	1	1
CO 94912	Toe plate assy.—L. H. D		1	1	1	1	1	1	1	1	1
CO 94913	Toe plate assy.—R. H. D		1	1	1	1	1	1	1	1	1
BO 94537	Toe plate steering gear cover plate		1	1	1	1	1	1	1	1	1
BO 18453	Toe plate screw		12	12	12	12	12	12	12	12	12
CO 94540	Front floor board—steel		1	1	1	1	1	1	1	1	1
CO 85708	Battery cover assy		1	1	1	1	1	1	1	1	1
CO 94947	Tool tray cover assy		1	1	1	1
CO 94948	Tool tray cover assy		1	1
CO 94949	Tool tray cover assy.		1
CO 85709	Center floor board		1	1	1	1	1	1	1	1	1
CO 94953	Rear floor board		1	1	1	1	1
CO 94954	Rear floor board		1	1
CO 94955	Rear floor board		1
CO 96359	Rear floor board		1
BO 93135	Front floor mat and pad assy		1	1	1	1	1	1	1	1	1
BO 93125	Rear floor mat assy.		1
BO 93126	Rear floor mat assy.		1
BO 93127	Rear floor mat assy.		1
BO 93123	Rear floor mat assy		1
BO 97003	Rear floor mat assy.		1	..

FLOOR—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp., S	Sub.
BO 97002	Rear floor mat assy		1
BO 97005	Rear floor mat assy	
BO 97006	Rear floor mat assy.		..	2	2	1
BO 97018	Auxiliary seat floor mat		1
BO 97019	Front floor side mat		2
BO 93137	Front floor side mat		..	1	1
BO 97007	Rear floor mat roller plate		..	1	1	1	1	1	1
BO 93124	Rumble seat toe board mat		1	1	1
BO 90088	Hand brake lever hole cover		1	1	1	1	1
BO 90089	Steering gear hole cover		1	1	1	1	1	1	1
BO 95430	Front door scuff plate—R. H.		1	1	1	1	1	1	1	..	1
BO 95431	Front door scuff plate—L. H.		1	1	1	1	..	1
BO 95432	Front door scuff plate—R. H.		1	1	1	..
BO 95433	Front door scuff plate—L. H.		1	1	1	..
BO 95434	Rear door scuff plate—R. H.	
BO 95435	Rear door scuff plate—L. H.	
BO 95436	Rear door scuff plate—R. H.		1	..
BO 95437	Rear door scuff plate—L. H.		1	..
BO 95438	Rear door scuff plate—R. H.		1	1
BO 95439	Rear door scuff plate—L. H.		1	1

SEATS

When seat cushions, backs and other upholstered seat parts are required, specify part, color, body model and car serial number

BO 94986	Front seat adjusting screw		1	1	1	1	1	1	1	1	2
BO 94983	Front seat adjusting screw nut		1	1	1	1	1	1	1	1	2
BO 94972	Seat adjusting handle assy.		2	1	1	2	2	2	2	2	3
BO 95897	Front seat adjusting screw bracket assy.		1	1	1	1	1	1	1	1	2
BO 81929	Front seat adjusting screw bracket anti-rattler		1	1	1	1	1	1	1	1	2
BO 95833	Front seat hinge bar assy.		..	1	1	1	1	1	1	1	..
BO 96945	Front seat hinge bar assy.		2	2
BO 94846	Front seat hinge bracket		2	2
BO 96321	Front seat hinge bracket		..	1	1	1	1	1	1	1	..
BO 70096	Front seat hinge to seat tray reinforcement bolt		4	4	4	4	4	4	4	4	4
BO 1483	Front seat hinge to seat frame bolt		..	4	4
BO 70933	Front seat hinge to seat frame bolt		4	4	4	4	4	4	4
BO 70674	Front seat hinge to seat frame bolt nut		..	4	4
BO 94987	Front seat adjusting roller		2	2	2	2	2	2	2	2	2
BO 70499	Front seat adjusting roller clevis pin		2	2	2	2	2	2	2	2	2
		2-29/32" from									
BO 95152	Front seat roller bracket—R. H.	top of bracket	..	1	1	1	1	1	1	1	..
BO 95153	Front seat roller bracket—L. H.	to center of lower roller hole	..	1	1	1	1	1	1	1	..
		1-29/32" from									
BO 96570	Front seat roller bracket—R. H.	top of bracket	..	1	1	1	1	..	1	1	..
BO 96571	Front seat roller bracket—L. H.	to center of roller lower hole	..	1	1	1	1	..	1	1	..
		1-7/16" from									
BO 96972	Front seat roller bracket—R. H.	top of bracket	1	1	1	..
BO 96973	Front seat roller bracket—L. H.	to center of lower hole	1	1	1	..
		2-1/4" from top									
BO 94993	Driver's seat roller bracket—R. H.	of bracket to	1	1
BO 94994	Driver's seat roller bracket—L. H.	center of lower hole	1	1
		1-7/8" from top									
BO 96942	Driver's seat roller bracket—R. H.	of bracket to	1	1
BO 96943	Driver's seat roller bracket—L. H.	center of lower hole	1	1
BO 95993	Passenger's seat rest	3-23/32" high	2	2
BO 96889	Passenger's seat rest	.3-3/16" high	2	2
BO 96939	Passenger's seat rest	.1-15/16" high	2	2

Specify serial number, body model and color on all painted or trimmed parts

SEATS—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S	Sub.
BO 70923	Passenger's seat rest bolt		4	4
BO 96011	Passenger's seat rest plate		2	2
BO 18482	Passenger's seat rest drive screw		2	2
BO 95641	Passenger's seat back hinge—R. H.—back half		1	1
BO 95642	Passenger's seat back hinge—L. H.—back half		1	1
BO 70004	Passenger's seat back hinge rivet (to panel)		8	8
BO 70896	Passenger's seat back hinge rivet (to trim rail)		4	4
BO 95643	Passenger's seat back hinge— R. H.—front half	1-25/32" from center of pin	1	1
BO 95644	Passenger's seat back hinge— L. H.—front half	hole to cushion support	1	1
BO 96940	Passenger's seat back hinge— R. H.—front half	2-17/32" from center of pin	1	1
BO 96941	Passenger's seat back hinge— L. H.—front half	hole to cushion support	1	1
BO 70933	Passenger's seat back hinge—front half—bolt		2	2
BO 95645	Passenger's seat back hinge pin		2	2
BO 70897	Passenger's seat back hinge lock nut		2	2
BO 94838	Rear seat adjusting screw	7-5/8" long	1	1
BO 96846	Rear seat adjusting screw	9-15/16" long	1	1
BO 94840	Rear seat adjusting screw	5-7/8" long	1	..	1	1	1	..
BO 94839	Rear seat adjusting screw	10-1/8" long	1
BO 96800	Rear seat adjusting screw	12-3/8" long	1
BO 94842	Rear seat adjusting screw bracket		1	1	1	1	1	1	1
BO 94843	Rear seat adjusting screw nut		1	1	1	1	1	1	1
BO 81929	Rear seat adjusting screw anti-rattler		1	1	1	1	1	1	1
BO 94841	Rear seat adjusting screw escutcheon		1	1	1	1
BO 94879	Rear seat adjusting roller		2	2	2	2	2	2	2
BO 94851	Rear seat adjusting roller bracket		2	2	2	2	2	2	2
BO 71113	Rear seat adjusting roller clevis pin		2	2	2	2	2	2	2
BO 95278	Arm rest hinge assy		1 Spec.	2	2	2	1
BO 70381	Arm rest hinge to front rest board bolt		3	3	3	..
BO 70786	Arm rest hinge to rest board bolt		3 Spec.	3	3	3	3
BO 95879	Arm rest hinge bracket—R. H		1 Spec.	2	2	2	1
BO 95880	Arm rest hinge bracket—L. H		1 Spec.	2	2	2	1
BO 70949	Arm rest hinge bracket to front back bolt		4	4	..
BO 70381	Arm rest hinge bracket to front back bolt		4 Spec.
BO 70786	Arm rest hinge bracket to front back bolt		4	4
BO 70911	Arm rest hinge bracket to rear back bolt		4	4	4	4
BO 95123	Rear seat hinge bar assy.		1	1	1	1	1	1	..
BO 95882	Rear seat back slide stud		1	1	1	1
BO 12481	Rear seat back slide lock nut		1	1	1	1
BO 771	Rear seat back slide spring washer		1	1	1	1
BO 71011	Rear seat back slide spring washer		1	1	1	1
BO 76426	Rear seat back slide stud spring		1	1	1	1
BO 82401	Rear seat slide button		2	2	2	2	2	2	2
BO 96997	Robe rail bracket screw tapping plate		2	2	..	2	2	..
CO 96737	Front seat cushion spring assy. (from car No. to.....)		1	1	..	1	1	..
CO 96998	Front seat cushion spring assy. (from car No. up.....)		1	1	..	1	1	..
CO 96952	Front seat cushion spring assy		1	1
CO 96397	Front seat cushion spring assy.		..	1	1	1
CO 96704	Front seat back spring assy.		..	1	1
CO 96740	Front seat back spring assy.		1 Spec.
CO 96086	Front seat back spring assy. (from car No. to)		1
CO 96739	Front seat back spring assy. (from car No. to.....)		1	1	..
CO 96993	Front seat back spring assy. (from car No. up.....)		1	1	..
CO 96087	Front seat back spring assy. (from car No. to.....)		1	1	1	..

SEATS—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw., S.	7 S.	To. S.	Sp. S.	Sub.
CO 96673	Front seat back spring assy. (from car No. to)		1	1
CO 96994	Front seat back spring assy. (from car No. up)		1	1
CO 95314	Front seat back spring assy. (from car No. to)		1
CO 96967	Front seat back spring assy. (from car No. up)		1
CO 96575	Front seat back spring assy.—R. H.		1
CO 96576	Front seat back spring assy.—L. H.		1
CO 95938	Rear seat cushion spring assy. (from car No. to)		1	1
CO 96017	Rear seat cushion spring assy. (from car No. up)		1	1	1	1	1	1	1
CO 96016	Rear seat back spring assy.		1	1
CO 96015	Rear seat back spring assy.		1
CO 95939	Rear seat back spring assy.—R. H.		1	1	1	..
CO 95940	Rear seat back spring assy.—L. H.		1	1	1	..
CO 96042	Rear seat back spring assy.—R. H.		1
CO 96043	Rear seat back spring assy.—L. H.		1
CO* 97247	Auxiliary seat—complete		2
CO* 96335	Auxiliary seat side rail—R. H.		2
CO* 96336	Auxiliary seat side rail—L. H.		2
BO* 70263	Auxiliary seat side rail to rear top board screw		4
BO* 96382	Auxiliary seat retaining plate		4
BO* 96338	Auxiliary seat bracket—R. H.		2
BO* 96339	Auxiliary seat bracket—L. H.		2
BO* 70242	Auxiliary seat bracket to retaining plate screw		8
BO* 96524	Auxiliary seat bracket reinforcement	
BO* 96358	Auxiliary seat floor pan		2
BO* 87279	Auxiliary seat floor spacer		1
BO* 96381	Auxiliary seat side rail hinge pin		4
BO* 70670	Auxiliary seat sill bracket to floor pan and sill rivet		24
BO* 70296	Auxiliary seat sill bracket to floor pan rivet	1/4"x5/8"	8
BO* 18454	Auxiliary seat sill bracket to floor pan rivet	3/16"x7/16"	12
BO* 70944	Auxiliary seat sill bracket to cross member rivet		8

*These parts also used on 7-Pass. Phaeton

INTERIOR FITTINGS

BO 95290	Dome lamp assy.		1	1	1	1	1	1	1	1	1
BO 95289	Dome lamp door assy		1	1	1	1	1	1	1	1	1
BO 95120	Dome lamp switch and escutcheon plate assy		1	1	1	1	1	1	1	1	1
BO 70467	Dome lamp switch wire screw		2	2	2	2	2	2	2	2	2
BO 96767	Rear vision mirror and clock assy.		1 Spec.	1	1	1	1
BO 96690	Rear vision mirror and clock bracket assy.		1 Spec.	1	1	1	1
BO 95288	Rear vision mirror assy.		1	1	1	1	1
BO 70324	Rear vision mirror screw		2	2	2	2	2	2	2	2	2
CO 95265	Foot rest assy.—complete (less trim)		1	1	1	1	1	1
BO 95220	Foot rest arm and bracket assy.—R. H.		1	1	1	1	1	1
BO 95221	Foot rest arm and bracket assy.—L. H.		1	1	1	1	1	1
CO 95225	Foot rest bar		1	1	1	1	1	1
BO 70889	Foot rest bar to arm screw		6	6.	6	6	6	6
BO 95812	Ash receiver assembly		2	..	2	2	2	2
BO 96040	Cigar lighter assy.		1 Spec.	1	1	1	1
BO 92320	Heating element assy. (specify color)		1 Spec.	1	1	1	1
BO 71030	Cigar lighter to panel nut		1 Spec.	1	1	1	1
BO 92335	Assist cord assy. (specify color)	
BO 92339	Assist cord assy. (specify color)		1	1
BO 92330	Assist cord assy. (specify color) (knitted end type)		1	1
BO 70044	Assist cord screw		8	8	8	8	8	8

INTERIOR FITTINGS—Continued

Part No.	Description	Specifications	Co.	Cp. (2)	Cp. (4)	S. S.	Tw. S.	7 S.	To. S.	Sp. S	Sub..
BO 92326	Robe hanger assy. (specify color) (knitted end type)		1	1
BO 92329	Robe hanger assy. (specify color) (knitted end type)		1
BO 92331	Robe hanger assy. (specify color) (knitted end type)	
BO 92334	Robe hanger assy. (specify color)		1	..
BO 92336	Robe hanger assy. (specify color)		1
BO 97556	Assist cord assy. (specify color) (bound end type)		1	1
BO 97331	Robe hanger assy. (specify color) (bound end type)		1	1
BO 97332	Robe hanger assy. (specify color) (bound end type)		1	1	1

REAR DECK

									Cp. (2)	Cp. (4)	Cp. S
CO 94165	Deck lid assy								1
CO 94166	Deck lid assy.								..	1	1
BO 95374	Deck lid check arms and bracket assy.—R. H								1
BO 95375	Deck lid check arms and bracket assy.—L. H								1
BO 18453	Deck lid check arms and bracket screw								8
BO 12120	Deck lid check arms and bracket nut								4
BO 94968	Deck door hinge assy. (door half)								2
BO 94796	Deck door hinge assy. (door half)								..	2	2
BO 95186	Deck door hinge (body half)—R. H.								..	1	1
BO 95187	Deck door hinge (body half)—L. H.								..	1	1
BO 95259	Deck drain trough to tie bar strainer—R. H								1	1	1
BO 95260	Deck drain trough to tie bar strainer—L. H								1	1	1
BO 95256	Deck drain trough to tie bar strainer bracket assy								2	2	2
BO 70882	Deck strainer to bracket bolt								4	4	4
BO 70676	Deck strainer to bracket nut								4	4	4
BO 70469	Deck strainer to tie bar bolt								4	4	4
BO 70676	Deck strainer to tie bar nut								4	4	4
BO 95044	Deck door hinge support assy.								..	2	2
BO 18465	Deck door hinge to panel bolt								..	8	8
BO 83191	Deck lid check bracket attaching plate								2
BO 95379	Deck door lock striker plate								1
BO 9159	Deck door lock striker plate bolt								2
BO 95377	Deck lid bumper bracket—R. H								1
BO 95378	Deck lid bumper bracket—L. H.								1
BO 95498	Deck lid bumper								2	2	2
BO 95494	Deck door weatherstrip—lower								1
BO 95496	Deck door weatherstrip—side								2	2	2
BO 95497	Deck door weatherstrip—front								1	1	1
BO 95058	Deck lid drain trough—upper								1
BO 95059	Deck lid drain trough—upper								..	1	1
BO 95060	Deck lid drain trough—side—R. H								1
BO 95061	Deck lid drain trough—side—L. H								1
BO 95062	Deck lid drain trough—side—R. H								..	1	1
BO 95063	Deck lid drain trough—side—L. H								..	1	1
BO 95192	Deck lid drain trough—rear								1
BO 95560	Deck lid lock assy								1
BO 81950	Deck lid lock assy								..	1	1
BO 18453	Deck lid lock screw								4
BO 70304	Deck lid lock screw								..	4	4
BO 95908	Deck lid handle and lock cylinder assy								..	1	1
BO 95909	Deck lid handle and lock cylinder assy								1

REAR DECK—Continued

Part No.	Description	Specifications	Cp.(2)	Cp.(4)	Cp.S
BO 95913	Deck lid handle assy. (less cylinder)		..	1	1
BO 95914	Deck lid handle assy. (less cylinder)		1
BO 70526	Deck lid handle to lid screw		2	2	2
BO 96866	Deck lid handle lock cylinder and keys assy		1	1	1

RUMBLE SEAT STEPS

BO 95723	Upper step assy		..	1	1
BZ 52961	Upper step to fender bolt		..	2	2
BO 70674	Upper step to fender bolt nut		..	2	2
BO 95722	Lower step assy.		..	1	1
BO 70047	Lower step bolt nut		..	2	2
BO 95956	Lower step bracket		..	1	1
BY 1061	Lower step bracket to bumper bolt		..	2	2
BZ 12415	Lower step bracket to bumper bolt nut		..	2	2

